



Installation

- Ensure the ground/surface for the reservoir is level
- Place the reservoir on the ground (use a bag of sand to level if required)
- Sit the sub base in the reservoir (some have a lid and don't require a sub base)
- Place the pump in the reservoir with the appropriate hose fitting
- Connect the flexible hose to the hard pipe at the base of the urn
- Place the urn on the sub base or lid and push the hose through the hole
- Connect the hose to the pump
- Check the sub base and urn are level
- Fill the reservoir and urn with water
- Switch on the pump
- One last check to make sure the water is running evenly over the urn

Sit back, relax and enjoy your new water feature!